


Grandstream Networks, Inc.

126 Brookline Ave, 3rd Floor
 Boston, MA 02215. USA
 Tel : +1 (617) 566 - 9300
 Fax: +1 (617) 249 - 1987
www.grandstream.com



In all EU member states, operation of 5150
 - 5350 MHz is restricted to indoor use only.



For Certification, Warranty and RMA information, please visit
www.grandstream.com



WP810

Enterprise Portable Wi-Fi Phone

Quick Installation Guide

Content

English.....	1
简体中文.....	6

The WP810 is not pre-configured to support or make emergency calls to any type of hospital, law enforcement agency, medical care unit ("Emergency Service(s)") or any other kind of Emergency Service. You must make additional arrangements to access Emergency Services. It is your responsibility to purchase SIP-compliant Internet telephone service, properly configure the WP810 to use that service, and periodically test your configuration to confirm that it works as you expect. It is also your responsibility to purchase traditional wireless or landline telephone services to access Emergency Services.

GRANDSTREAM DOES NOT PROVIDE CONNECTIONS TO EMERGENCY SERVICES VIA THE WP810. NEITHER GRANDSTREAM NOR ITS OFFICES, EMPLOYEES OR AFFILIATES MAY BE HELD LIABLE FOR ANY CLAIM, DAMAGE, OR LOSS, AND YOU HEREBY WAIVE ANY AND ALL SUCH CLAIMS OR CAUSES OF ACTION ARISING FROM OR RELATING TO YOUR INABILITY TO USE THE WP810 TO CONTACT EMERGENCY SERVICES, AND YOUR FAILURE TO MAKE ADDITIONAL ARRANGEMENTS TO ACCESS EMERGENCY SERVICES IN ACCORDANCE WITH THE IMMEDIATELY PRECEDING PARAGRAPH.

The GNU GPL license terms are incorporated into the device firmware and can be accessed via the Web user interface of the device at *my_device_ip/gpl_license*. It can also be accessed here: <http://www.grandstream.com/legal/open-source-software>
To obtain a CD with GPL source code information please submit a written request to info@grandstream.com

PRECAUTIONS

- Do not attempt to open, disassemble, or modify the device.
- Do not use a third party power adapter.
- Do not expose the device to temperatures outside the range of -20°C to 60°C.
- Do not expose the WP810 at environments outside of the humidity range of 10-90% RH (non-condensing).

OVERVIEW

The WP810 is a portable Wi-Fi phone designed to suit a variety of enterprises and vertical market applications, including retail, logistics, medical and security. This powerful, portable Wi-Fi phone comes equipped with integrated dual-band 802.11a/b/g/n/ac Wi-Fi support, advanced antenna design and roaming support. By adding HD voice with dual-MICs, the WP810 offers a powerful combination of features, mobility and durability to suit all portable telephony needs.

WP810 PACKAGE CONTENTS




1x WP810 Handset



1x Rechargeable Battery




1x Charging Station



1x Handset Belt Clip



1x 5V Power Adapter




1x Quick Installation Guide

SETTING UP THE WP810

Charging Station:


Plug the power adapter into a power source socket to start using the charging station.



Handset:


- Open the battery cover.
- Insert the battery with the electrodes in the bottom left corner.
- Close the battery cover.

Note: Please charge the battery fully before using the handset for the first time.



~3~

WP810 DESCRIPTION



~4~

CONNECTING WP810 TO WI-FI NETWORK

1. On LCD menu, press Menu key and navigate to Settings → Network Settings → Wi-Fi.
2. Set Wi-Fi to "On" and navigate to "Wi-Fi Settings". A list of Wi-Fi networks will be displayed.
3. Select the desired network to connect to. (Enter the correct password to connect if requested)


WP810 will display Wi-Fi icon on top of the main LCD menu if the connection to the Wi-Fi network is successful.

ACCESSING WP810 WEB GUI

1. Press the UP button to see the IP address.
2. Type the phone's IP address in your PC browser.

Note: The computer needs to be on same network as WP810.

3. Enter admin's username and password to access the configuration menu. (The factory default username is "admin" while the default random password can be found on the sticker at the back of the unit).



Refer to online documents and FAQ for more detailed information: <http://www.grandstream.com/our-products>

WP810不预设对医院、执法机构、医疗中心(急救服务)以及各种紧急服务的紧急通话服务。用户必须自行设定紧急通话功能。用户必须自行购买SIP兼容的网络电话服务，正确地设定WP810使用该服务，并定期测试您的配置以确保WP810如预期工作，否则请购买传统无线或有线电话服务来拨打紧急通话。

Grandstream Networks 公司的WP810不支持紧急通话服务。Grandstream Networks公司、其管理者和员工以及其相关机构对此所造成的任何索赔、损失或者损害都不负有任何法律追究责任。在此，您将无权对任何以及所有由于无法通过WP810拨打紧急电话以及没有遵照前段文字描述而造成紧急通话失败的事件提出诉讼。

GNU GPL许可条款已包含在设备固件中，可以通过设备的Web用户界面 `my_device_ip/gpl_license` 进行访问。也可以通过以下链接访问：<http://www.grandstream.com/legal/open-source-software>

如果需要包含GPL源代码信息的CD，请发邮件到 info@grandstream.com 提交请求。

注意事项

- 请不要打开、拆卸或修改该设备。
- 请不要使用第三方的电源适配器。
- 不要将本设备暴露在温度-20 C至60 C以外。
- 不要将本设备暴露在环境湿度如下范围以外：10-90%RH（无冷凝）。


产品概览

WP810是一款便携式Wi-Fi手机，旨在满足各种企业和垂直市场的应用需求，包括零售，物流，医疗和安全。这款功能强大的便携式电话配备了双频802.11a /b/g/n/ac Wi-Fi，先进的天线设计并支持漫游。通过增加高清语音的双麦克风，WP810提供了功能性，移动性和耐用性的强大组合，可满足所有便携式电话的需求。

WP810 设备包装清单



WP810手柄
(1个)



充电电池
(1个)




充电座 (1个)



手柄皮带夹
(1个)



5V 电源适配器
(1个)




快速安装指南 (1本)

~7~

配置WP810

充电站:

将电源适配器插入电源插座以开始使用 充电座。






手柄:

- 打开电池盖。
- 将电池的电极端插入左下角。
- 合上电池盖。


注意：在首次使用手柄之前请将电池充满电。

- 1: 电池盖
- 2: 电池
- 3: 手柄后部



~8~

WP810 简介



连接WP810至WI-FI网络

1. 在LCD菜单中，按菜单键和导航键至：设置 → 网络设置。
2. 按下“上”方向键，此时电话屏幕显示话机IP地址；
3. 选择想要连接的网络。（如果要求，请输入正确的密码进行连接）如果与Wi-Fi网络的连接成功，WP810将在LCD主页顶部显示Wi-Fi状态图标。

打开WP810网页用户界面

1. 按下“上”方向键，此时电话屏幕显示话机IP地址；
 2. 在您电脑浏览器中输入话机IP地址。
- 注意：电脑和WP810应在同一网络中。
3. 输入管理员账号及密码，进入配置页面。（出厂默认用户名为“admin”，出场默认随机密码可以在设备背后的贴纸上找到）。



欲获取详细的话机使用信息，请在以下链接中下载WP810用户手册：
<http://www.grandstream.com/our-products>